




Number **5-A**

*Adjust Aerial and Equalizing Condensers in Accordance
with the Following Information*



Special Note: When making these adjustments, use about ten feet of antenna wire if local station is used and regular antenna if distant station is used.